

AES 1-2

15 HI
2 LO
1 GND

AES 3-4

16 HI
3 LO
14 GND


AES 5-6*

17 HI
4 LO
13 GND

AES 7-8

18 HI
5 LO
26 GND

* THE AES SYNC IS TAKEN ON AES
INPUT 5-6



TIME CODE IN

19 HI
6 LO
20 GND

WORLD CLOCK IN or
VIDEO IN

7 INPUT SIGNAL
20 GND

WORLD CLOCK OUT

8 OUTPUT SIGNAL
20

SERIAL BUS

22 TX HI
9 TX LO
23 RX HI
10 RX LO
11 INT
21 DV

MONITOR OUT

25 LEFT
12 RIGHT
24 GND MONITOR

MINIR 82 ACCESSORY CONNECTOR
SONOSAX PART NUMBER 860570